The Sensitive Backpack

Niklas Hösl - Magdalena Radinger



Motivation



react on

Context









Requirements

- Arduino-based sensor system
 - Detect context
 - Activities: running, walking, standing
 - Accelerometer
 - Backpack open / closed
 - Light sensor



Wiring




fritzing

Activity detection algorithm I

- 1 sample = Absolute acceleration vector in g
- $a = \sqrt{x^2 + y^2 + z^2} g$

- Sample Frequency: 20 Hz
- First approach:
 - Sum (smoothed) accelerations
 - Pro: Easy to compute
 - o Con:
 - Not very robust
 - Takes 4sec to detect activity
 - Still time left to find better method!



Activity detection algorithm II

- Better approach: Detect steps and step frequency
 - More complex (lots of preprocessing)
 - Low Memory/CPU Usage:
 - Solved with 3 Int-Ringbuffers
- Activities:
 - Standing: No step for 1.25s
 - Walking: < 2 Steps/sec
 - Running >= 2 Steps/sec




Figure 6. Dynamic threshold and dynamic precision.

